

View Port Forwarding Settings on the SPA8000 Analog Telephone Adapter

Objective

Port Forwarding allows the administrator to decide which computer in the Local Area Network (LAN) the data packets should go bases on the port that it is used for the connection. The administrator may need port forwarding because Network Address Translation (NAT) allows several computers to be hidden behind a router. The objective of this article is to explain how to see the port forwarding settings on a SPA8000.

Applicable Device


- SPA8000

Software Version

- 6.1.12

Port Forwarding Settings

Step 1. Log in to the web configuration utility as an administrator and choose **Advanced > Network > Application**. The *Application* page opens:



The screenshot shows the web configuration utility interface. At the top, there are tabs for 'Network' and 'Voice'. Under 'Network', there are sub-tabs for 'Status', 'Wan Status', 'Lan Status', and 'Application'. The 'Application' tab is selected. Below the tabs, there are links for 'Trunk Status', 'Admin Login', 'basic', and 'advanced'. The main content area is titled 'Port Forwarding Settings' and contains a table with the following data:

Enable	Service Name	Starting Port	Ending Port	Protocol	Server IP Address
yes	sip2L1	5160	5160	Both	192.168.1.2
yes	sip2L2	5161	5161	Both	192.168.1.2
yes	tcp2	5160	5180	Both	192.168.1.2
yes	rtp2	17384	17482	Both	192.168.1.2
yes	sip3L1	5260	5260	Both	192.168.1.3
yes	sip3L2	5261	5261	Both	192.168.1.3
yes	tcp3	5260	5280	Both	192.168.1.3
yes	rtp3	18384	18482	Both	192.168.1.3
yes	sip4L1	5360	5360	Both	192.168.1.4
yes	sip4L2	5361	5361	Both	192.168.1.4
yes	tcp4	5360	5380	Both	192.168.1.4
yes	rtp4	19384	19482	Both	192.168.1.4

The following port forwarding settings can be viewed on the *Application* page and under the Port Forwarding Settings area:

Note: The starting/ending port in the range used for this device indicate that the ports that come within this range use the corresponding protocol to transfer and receive data.

- Enable — Represents whether the port forwarding service is enabled or not. Yes indicates the service is enabled and No indicates the service is disabled.
- Service Name — Represents the name of the service that the port used to forward data.
- Starting Port — Represents the first port in the range used for this device.
- Ending Port — Represents the last port in the range used for this device.

- Protocol — Represents which protocol the corresponding port range uses to send and receive the data. The options are TCP, UDP, and Both.
 - TCP — Transmission Control Protocol (TCP) is used to efficiently manage the tracking of the data through Internet through the division of packets in different units. TCP provides reliable delivery of the data to the end user.
 - UDP — User Datagram Protocol (UDP) is used to efficiently manage the tracking of the data through Internet without the division of data in packets. UDP does not ensure the complete packet arrival to the end user.
 - Both — Both protocols UDP and TCP are used.
- Server IP Address — Displayed the LAN address of the device that it is connected to the port that forwards and receives the data.