SG350X、Sx550X:无法更改交换机上的XG端口 设置

确定日期

2016年3月30日

解决日期

不适用

受影响的产品

型号	固件版 本	固定于	
SG350X、Sx550X	2.2.0.x	2.3.0.13 0	

问题说明

XG端口设置不能通过交换机的基于Web的实用程序更改为禁用协商并同时设置速度。

分辨率

将交换机的固件升级到最新版本。如需指导,请点击这里。

解决方法

如果由于某种原因不想升级交换机的固件,可以执行以下解决方法:

步骤1.登录交换机的基于Web的实用程序。默认用户名和密码为cisco/cisco。

注意:如果已更改密码或创建了新帐户,请输入新凭据。

ahaha	Switch			
cisco	Cinton	Application:	Switch Manag	gement ᅌ
		Username:	cisco	
		Password:	•••••	
		Language:	English 🖨	
			Log In	Secure Browsing (HTTPS)
		Password: Language:	English 🖨	Secure Browsing (HTTP

步骤2.选择Port Management > Port Settings。



步骤3.在端口设置表中,单击与要配置的端口对应的单选按钮,然后单击**编辑**。

Port Settings Table										
Filte	Filter: Interface Type equals to Port of Unit 1 🛊 Go									
	Entry No.	Port	Description	Port Type	Operational Status	Port Speed	Duplex Mode	LAG	Protection State	
\bigcirc	1	XG1		10G-Copper	Down				Unprotected	
$\ \boxed{}$	2	XG2		10G-Copper	Up	10G	Full		Unprotected	
$\overline{\bigcirc}$	3	XG3		10G-Copper	Up	10G	Full		Unprotected	
\bigcirc	4	XG4		10G-Copper	Down				Unprotected	
\bigcirc	5	XG5		10G-Copper	Down				Unprotected	
\bigcirc	6	XG6		10G-Copper	Down				Unprotected	
\bigcirc	7	XG7		10G-Copper	Down				Unprotected	
\bigcirc	8	XG8		10G-Copper	Down				Unprotected	
\bigcirc	9	XG9		10G-FiberOptics	Down				Unprotected	
\bigcirc	10	XG10		10G-FiberOptics	Down				Unprotected	
\bigcirc	11	XG11		10G-FiberOptics	Down				Unprotected	
\bigcirc	12	XG12		10G-FiberOptics	Down				Unprotected	
\bigcirc	13	XG13		10G-FiberOptics	Down				Unprotected	
\bigcirc	14	XG14		10G-FiberOptics	Down				Unprotected	
\bigcirc	15	XG15		10G-FiberOptics	Down				Unprotected	
\bigcirc	16	XG16		10G-FiberOptics	Down				Unprotected	
\bigcirc	17	OOB		1000M-Copper	Up	1000M	Full	N/A	N/A	
	Copy Sett	ings	Ed	it						

注意:在本例中,选择XG2。

步骤4.取消选中Auto Negotiation Enable复选框**以禁**用自动协商,然后单击**Apply**。

Auto Negotiation:	Enable	Operational Auto Negotiation:	Enabled
Administrative Port Speed	: 100M 1000M 10G	Operational Port Speed:	10G
Auto Advertisement:	 Max Capability 1000 Full 100 Full 10000 Full 	Operational Advertisement:	Max Capability
Preference Mode:	 Slave Master 		
Neighbor Advertisement:	100 Full 1000 Full 10000 Full		
Flow Control:	 Enable Disable Auto Negotiation 		
MDI/MDIX:	MDIX MDI Auto	Operational MDI/MDIX:	MDIX
Protected Port:	Enable		
		Member in LAG:	
Apply Close			

步骤5.从Administrative Port Speed区域点击端口速度。

Administrative Port Speed:

000M

Operational Auto Negotiation: Operational Port Speed:

注意:在本例中,选择1000M。

步骤6.单击"应用",然后单击"关闭"。

Auto Negotiation:	Enable	Operational Auto Negotiation:		
Administrative Port Speed	: 00M • 1000M • 10G	Operational Port Speed:		
Auto Advertisement:	 Max Capability 1000 Full 100 Full 10000 Full 	Operational Advertisement: Unknown		
Preference Mode:	Slave Master			
Neighbor Advertisement:	Unknown			
Flow Control:	 Enable Disable Auto Negotiation 			
MDI/MDIX:	MDIX MDI Auto	Operational MDI/MDIX:		
Protected Port:	Enable			
		Member in LAG:		
Apply Close				

步骤7.(可选)单击"保存"按钮将设置保存到启动配置文件。

				(⊗ Save	cisco La	anguage:	English	•	
F8T 16-Port 10G Stackable Managed Switch										
Port Settings										
Jumbo Frames: Enable										
Jur	nbo frames o	onfigurat	tion changes w	vill take effect after s	aving the configuratio	n and rebo	poting the	switch.		
Apply Cancel										
Por	t Settings Ta	able								
Filte	er: Interface	<i>Type</i> eq	uals to Port	of Unit 1 🖨 🛛 Go						
	Entry No.	Port	Description	Port Type	Operational Status	Port	Duplex	LAG	Protection	
						Speed	Mode		State	
\bigcirc	1	XG1		10G-Copper	Down				Unprotected	
\bigcirc	2	XG2		10G-Copper	Up	1000M	Full		Unprotected	
\bigcirc	3	XG3		10G-Copper	Up	10G	Full		Unprotected	
\bigcirc	4	XG4		10G-Copper	Down				Unprotected	

o