



Cisco RF Gateway 1 Front Panel Replacement Installation Instructions

Overview

Introduction

The purpose of this document is to provide users with installation instructions for replacing the RF Gateway 1 front panel.

Audience

This document is intended for system engineers or managers responsible for operating and/or maintaining this product.

Related Publications

Refer to the following documents for additional information regarding hardware and software.

- *Cisco RF Gateway 1 System Guide*, part number 4024958
- *Cisco RF Gateway 1 Configuration Guide*, part number 4025112

Replacing the RF Gateway 1 Front Panel


Follow the instructions below to replace the front panel.



WARNING:

- When the front panel is removed, an ESD wrist strap should be used to prevent damage to the device.
- To prevent unpredictable LCD behavior, it is recommended that the unit be turned off when replacing the front panel.

- 1 Turn off the chassis.
- 2 Loosen the thumb screws on the front of the chassis and remove the front panel.
Important: Make sure the wrist strap is attached.
- 3 Remove the ribbon cable from the circuit board between the two fans on the left side of the chassis.



T13863

- 4 Connect the ribbon cable from the new front panel to the connector from which the old ribbon cable was removed.
- 5 Replace the front panel, taking care not to pinch the ribbon cable.
- 6 Tighten the thumb screws.

Customer Service Contact Information

Region	Centers	Customer Service Numbers
North America	USA	■ Toll-free: 1-800-722-2009
Europe, Middle East, Africa	Belgium	■ Telephone: 32-56-445-133 or 32-56-445-118
Japan	Japan	■ Telephone: 81-3-5908-2153 or +81-3-5908-2154
Korea	Korea	■ Telephone: 82-2-6205-6004
China (mainland)	China	■ Telephone: 86-21-6237-5233
Other Asia-Pacific countries, Australia	Hong Kong	■ Telephone: 852-2522-5059
Brazil	Brazil	■ Telephone: 55-11-3845-9154, ext 109
Mexico, Central America, Caribbean	Mexico	■ Telephone: 52-55-50-81-8425
All other Latin America countries	Argentina	■ Telephone: 770-236-5662



Cisco Systems, Inc.
5030 Sugarloaf Parkway, Box 465447
Lawrenceville, GA 30042

678 277-1120
800 722-2009
www.cisco.com

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of cisco trademarks, go to this URL:

www.cisco.com/go/trademarks.

Third party trademarks mentioned are the property of their respective owners.

The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Product and service availability are subject to change without notice.

© 2008, 2012 Cisco and/or its affiliates. All rights reserved.

August 2012 Printed in USA

Part Number 4028365 Rev B