

SPA3102 の [Interactive Voice Response (IVR)] メニューへのアクセス

目的

音声自動応答装置は、デバイス内のさまざまな設定の手順を提供します。これらの手順は、電話機がデバイスに接続されたときに取得されます。このドキュメントでは、SPA3102のInteractive Voice Response(IVR)メニューについて詳しく説明します。

該当するデバイス

- ・ SPA8000
- ・ SPA3102
- ・ SPA9000
- ・ SPA2102
- ・ SPA112
- ・ PAP2T

[Software Version]

- ・ v6.1.12

音声自動応答装置(IVR)メニュー

[Interactive Voice Response]メニューへのアクセス

ステップ1：音声ゲートウェイのPHONEポートに接続された電話機を使用します。Interactive Voice Response Menu(IVR)には、アナログ電話からのみアクセスできます。

ステップ2：アスタリスク(*)キーを4つ押します。

ステップ3：音声プロンプト「Linksys configuration menu」が表示されるまで待ちます。オプションの後に# (シャープ) キーを入力するか、終了するには電話を切ってください。

ステップ4：次の表に、アクション、コマンド、メニューの選択肢、説明を示します。オプションを選択したら、# (シャープ) キーを押します。メニューを終了するには、電話を切ります。

音声自動応答装置メニュー

IVR Action	IVR Menu	Parameter(s)	Notes
Activate IVR Menu	****	None	Ignore SIT or other tones until you hear, "Sipura configuration menu. Please enter option followed by the pound key or hang-up to exit."
Check WAN IP Address	110	None	IVR will announce the IP address of the WAN port
Check WAN Network Mask	120	None	IVR will announce the network mask of the WAN port
Check WAN Gateway	130	None	IVR will announce the gateway of the WAN port
Check MAC Address	140	None	IVR will announce MAC address of the SPA-2100
Check Firmware Version	150	None	IVR will announce the firmware version running on SPA-2100
Check Primary DNS Server IP Address	160	None	IVR will announce the primary DNS server IP address
Check WAN Port Web Server Port	170	None	IVR will announce the WAN port web server port
Check LAN IP Address	210	None	IVR will announce the IP address of the LAN port
Check WAN Internet Connection Type	100	None	IVR will announce the WAN Internet Connection Type
Set WAN Internet Connection Type (see "Wan Setup" -> "Internet Connection Settings")	101	Enter 0 to use DHCP Enter 1 to use Static IP Enter 3 to use PPPoE	Requires Password
Set Static IP address (WAN Port)	111	Enter IP address using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Network Mask	121	Enter network mask using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Gateway	131	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set Primary DNS Server IP Address	161	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	Requires Password.
		Press 0 to select the router/NAT mode.	If the Voice Gateway acts as the router for your network, use the

注：管理者パスワードが設定されていない場合、またはユーザーがパスワードを変更できる場合は、「パスワードが必要」とマークされた項目には、パスワードは必要ありません。