

# WDS on Cisco Autonomous Access Points Version 15.2(4)JA with Local RADIUS Server Configuration Example



Document ID: 116597

Contributed by Maithri B and Surendra BG, Cisco TAC Engineers.

Oct 18, 2013

## Contents

### Introduction

#### Prerequisites

- Requirements

- Components Used

#### Configure

- GUI Configurations

  - Create the SSID

  - Local RADIUS Server Configuration on WDS AP

  - Local RADIUS Server Configuration on WDS Client AP

  - Enable WDS on WDS AP

  - Enable WDS on WDS Client AP

- CLI Configurations

  - WDS AP

  - WDS Client AP

#### Verify

- CLI Verification Output on WDS AP

- CLI Verification Output on WDS Client AP

#### Troubleshoot

## Introduction

This document describes how to configure Wireless Domain Services (WDS) on an autonomous access point (AP) setup with a local RADIUS server. The document focuses on configurations through the new GUI, but also provides command-line interface (CLI) configurations.

## Prerequisites

### Requirements

Cisco recommends that you have knowledge of basic GUI and CLI configuration on autonomous APs.

### Components Used

The information in this document is based on these software and hardware versions:

- Cisco 3602e Series Access Point on Autonomous AP IOS<sup>®</sup> Software, Release 15.2(4)JA1; this device will act as a WDS AP and local RADIUS server.

- Cisco 2602i Series Access Point on Autonomous AP IOS Software, Release 15.2(4)JA1; this device will act as a WDS client AP.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

## Configure


**Note:** Use the Command Lookup Tool (registered customers only) in order to obtain more information on the commands used in this section.

## GUI Configurations


### Create the SSID

This procedure describes how to create a new Service Set Identifier (SSID).

1. Navigate to **Security > SSID Manager**, and click **NEW** in order to create a new SSID.



2. Configure the SSID for Extensible Authentication Protocol (EAP) authentication.



3. Set the desired encryption level. In this example, use Wi-Fi Protected Access 2 (WPA2).

The screenshot shows the 'Client Authenticated Key Management' configuration page. It includes several settings: 'Key Management' is set to 'Mandatory'; 'WPA Pre-shared Key' is an empty text field; '11w Configuration' is set to 'Optional'; '11w Association comeback' is set to '1000'; and '11w Saquery retry' is set to '100'. There are also checkboxes for 'COCKM', 'Enable WPA', and 'Enable WPA2'. A dropdown menu for 'WPA2' is open, showing options: 'WPA2', 'WPA', 'WPAv1', 'WPAv2', 'WPAv2 dot11r', and 'WPAv2 dot11r'. The 'WPAv2' option is selected.

4. Click **Apply** in order to save the settings.

5. Navigate to **Security > Encryption Manager**, and choose the required encryption cipher method.

The screenshot shows the 'Security > Encryption Manager' configuration page for 'RADIO0-802.11N<sup>2.4GHZ</sup>'. The page title is 'Security: Encryption Manager - Radio0-802.11N<sup>2.4GHZ</sup>'. The 'Encryption Modes' section has three radio buttons: 'None', 'WEP Encryption', and 'Cipher'. The 'Cipher' radio button is selected. A dropdown menu is open, showing the following options: 'WEP 128 bit', 'WEP 40 bit', 'TKIP', 'CKIP', 'CMIC', 'CKIP-CMIC', 'TKIP + WEP 128 bit', 'TKIP + WEP 40 bit', 'AES CCMP', 'AES CCMP + TKIP', 'AES CCMP + TKIP + WEP 128 bit', and 'AES CCMP + TKIP + WEP 40 bit'. The 'AES CCMP' option is selected. The 'Encryption Keys' section is partially visible, showing 'Encryption Key 4'.


## Local RADIUS Server Configuration on WDS AP

This procedure describes how to configure the local RADIUS server on the WDS AP:


1. Navigate to **Security > Server Manager**, add the WDS AP Bridge Virtual Interface (BVI) IP as the local RADIUS, and add a shared secret.



2. Navigate to *Security > Local Radius Server > General Set-Up* tab. Define the EAP protocols you wish to use. In this example, enable Light Extensible Authentication Protocol (LEAP) authentication.



3. You can also add Network Access Server (NAS) IPs and client username/password credentials on the same page. The configuration of a local RADIUS on a WDS AP is complete.



## Local RADIUS Server Configuration on WDS Client AP

This figure shows how to configure the IP address of the WDS AP as the RADIUS server:

Corporate Servers

Current Server List

RADIUS

Server Name	Server	Shared Secret
<NEW> WDS-Radius		

IP Version:  IPV4  IPV6

Server Name: WDS-Radius

Server: 10.106.54.148 (Hostname or IP Address)

Shared Secret: \*\*\*\*\*

Authentication Port (optional): 1812 (0-65536)

Accounting Port (optional): 1813 (0-65536)

Delete Apply Cancel

Both APs are now configured with SSIDs for LEAP authentication, and the WDS server acts as the local RADIUS. Use the same steps for an external RADIUS; only the RADIUS server IP will change.

### Enable WDS on WDS AP

This procedure describes how to enable WDS on the WDS AP:

1. Navigate to **Wireless > WDS > General Set-Up** tab, and enable the check box **Use this AP as Wireless Domain Services**. This enables the WDS service on the AP.
2. In a network with multiple WDS APs, use the Wireless Domain Services Priority option in order to define the primary WDS and the backup WDS. The value ranges from 1–255, where 255 is the highest priority.

Wireless Services

AP

WDS

WDS STATUS GENERAL SET-UP SERVER GROUPS

Hostname: MNB.WDS.AP MNB.WDS.AP uptime is 9 hours, 59 minutes

Wireless Services: WDS/WHM - General Set-Up

WDS - Wireless Domain Services - Global Properties

Use this AP as Wireless Domain Services

Wireless Domain Services Priority: 204 (1-255)

Use Local MAC List for Client Authentication


WHM - Wireless Network Manager - Global Configuration

Configure Wireless Network Manager

Wireless Network Manager Address: DISABLED (IP Address or Hostname)

Apply Cancel

3. Navigate to the **Server Groups** tab on the same page. Create an infrastructure server group list, to which all the WDS client APs will authenticate. You can use the local RADIUS server on the WDS AP for this purpose. Since it has already been added, it appears in the drop-down list.




4. Enable the radio button *Use Group For: Infrastructure Authentication*, and click *Apply* in order to save the settings.
5. The WDS AP username and passwords can be added to the local RADIUS server list.

## Enable WDS on WDS Client AP

This procedure describes how to enable WDS on the WDS client AP:

1. Navigatge to *Wireless > AP*, and enable the check box for *Participate in SWAN Infrastructure*. SWAN stands for Structured Wireless–Aware Network.



2. WDS client APs can auto discover the WDS APs. Or, you can manually enter the IP address of the WDS AP for client registration in the *Specified Discovery* text box.

You can also add the WDS client username and password for authentication against the local RADIUS server configured on the WDS AP.

## CLI Configurations

### WDS AP

This is a sample configuration for the WDS AP:

```
Current configuration : 2832 bytes
!
! Last configuration change at 05:54:08 UTC Fri Apr 26 2013
```

```
version 15.2
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
service password-encryption
!
hostname MAIB-WDS-AP
!
!
logging rate-limit console 9
enable secret 5 $1$EdDD$dG47yIKn86GCqmKjFf1Sy0
!
aaa new-model
!
!
aaa group server radius rad_eap
server name Local-Radius
!
aaa group server radius Infrastructure
server name Local-Radius
!
aaa authentication login eap_methods group rad_eap
aaa authentication login method_Infrastructure group Infrastructure
aaa authorization exec default local
!
!
!
!
!
aaa session-id common
no ip routing
no ip cef
!
!
!
!
dot11 syslog
!
dot11 ssid WDS-EAP
authentication open eap eap_methods
authentication network-eap eap_methods
authentication key-management wpa version 2
guest-mode
!
!
dot11 guest
!
!
!
username Cisco password 7 13261E010803
username My3602 privilege 15 password 7 10430810111F00025D56797F65
!
!
bridge irb
!
!
!
interface Dot11Radio0
no ip address
no ip route-cache
!
encryption mode ciphers aes-ccm
!
ssid WDS-EAP
!
antenna gain 0
```

```
stbc
station-role root
bridge-group 1
bridge-group 1 subscriber-loop-control
bridge-group 1 spanning-disabled
bridge-group 1 block-unknown-source
no bridge-group 1 source-learning
no bridge-group 1 unicast-flooding
!
interface Dot11Radiol
no ip address
no ip route-cache
!
encryption mode ciphers aes-ccm
!
ssid WDS-EAP
!
antenna gain 0
peakdetect
dfs band 3 block
stbc
channel dfs
station-role root
bridge-group 1
bridge-group 1 subscriber-loop-control
bridge-group 1 spanning-disabled
bridge-group 1 block-unknown-source
no bridge-group 1 source-learning
no bridge-group 1 unicast-flooding
!
interface GigabitEthernet0
no ip address
no ip route-cache
duplex auto
speed auto
bridge-group 1
bridge-group 1 spanning-disabled
no bridge-group 1 source-learning
!
interface BVI1
ip address 10.106.54.146 255.255.255.192
no ip route-cache
ipv6 address dhcp
ipv6 address autoconfig
ipv6 enable
!
ip forward-protocol nd
ip http server
no ip http secure-server
ip http help-path http://www.cisco.com/warp/public/779/smbiz/prodconfig/help/eag
ip radius source-interface BVI1
!
!
radius-server local
no authentication eapfast
no authentication mac
nas 10.106.54.146 key 7 045802150C2E1D1C5A
user WDSClient1 nhash 7
072E776E682F4D5D35345B5A227E78050D6413004A57452024017B0803712B224A
!
radius-server attribute 32 include-in-access-req format %h
radius-server vsa send accounting
!
radius server Local-Radius
address ipv4 10.106.54.146 auth-port 1812 acct-port 1813
key 7 060506324F41584B56
```



```

!
bridge 1 route ip
!
!
wlccp authentication-server infrastructure method_Infrastructure
wlccp wds priority 254 interface BV11
!
line con 0
line vty 0 4
transport input all
!
end

```

## WDS Client AP

This is a sample configuration for the WDS client AP:

```

Current configuration : 2512 bytes
!
! Last configuration change at 00:33:17 UTC Wed May 22 2013
version 15.2
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
service password-encryption
!
hostname MAIB-WDS-Client
!
!
logging rate-limit console 9
enable secret 5 $1$vx/M$qp6DY30TGixmjvUDvKKjk/
!
aaa new-model
!
!
aaa group server radius rad_eap
server name WDS-Radius
!
aaa authentication login eap_methods group rad_eap
aaa authorization exec default local
!
!
!
!
aaa session-id common
no ip routing
no ip cef
!
!
!
!
dot11 syslog
!
dot11 ssid WDS-EAP
authentication open eap eap_methods
authentication network-eap eap_methods
authentication key-management wpa version 2
guest-mode
!
!
dot11 guest
!
eap profile WDS-AP
method leap

```

```
!  
!  
!  
username Cisco password 7 062506324F41  
username My2602 privilege 15 password 7 09414F000D0D051B5A5E577E6A  
!  
!  
bridge irb  
!  
!  
!  
interface Dot11Radio0  
no ip address  
no ip route-cache  
!  
encryption mode ciphers aes-ccm  
!  
ssid WDS-EAP  
!  
antenna gain 0  
stbc  
station-role root  
bridge-group 1  
bridge-group 1 subscriber-loop-control  
bridge-group 1 spanning-disabled  
bridge-group 1 block-unknown-source  
no bridge-group 1 source-learning  
no bridge-group 1 unicast-flooding  
!  
interface Dot11Radio1  
no ip address  
no ip route-cache  
!  
encryption mode ciphers aes-ccm  
!  
ssid WDS-EAP  
!  
antenna gain 0  
peakdetect  
dfs band 3 block  
stbc  
channel dfs  
station-role root  
bridge-group 1  
bridge-group 1 subscriber-loop-control  
bridge-group 1 spanning-disabled  
bridge-group 1 block-unknown-source  
no bridge-group 1 source-learning  
no bridge-group 1 unicast-flooding  
!  
interface GigabitEthernet0  
no ip address  
no ip route-cache  
duplex auto  
speed auto  
bridge-group 1  
bridge-group 1 spanning-disabled  
no bridge-group 1 source-learning  
!  
interface BVI1  
ip address 10.106.54.136 255.255.255.192  
no ip route-cache  
ipv6 address dhcp  
ipv6 address autoconfig  
ipv6 enable  
!
```

```

ip forward-protocol nd
ip http server
no ip http secure-server
ip http help-path http://www.cisco.com/warp/public/779/smbiz/prodconfig/help/eag
ip radius source-interface BVI1
!
!
radius-server attribute 32 include-in-access-req format %h
radius-server vsa send accounting
!
radius server WDS-Radius
address ipv4 10.106.54.146 auth-port 1812 acct-port 1813
key 7 110A1016141D5A5E57
!
bridge 1 route ip
!
!
wlccp ap username WDSClient1 password 7 070C285F4D06485744
wlccp ap wds ip address 10.106.54.146
!
line con 0
line vty 0 4
transport input all
!
end

```

## Verify

Use this section to confirm that your configuration works properly. Once the setup is complete, the WDS client AP should be able to register to the WDS AP.

On the WDS AP, the WDS status is shown as Registered.

WDS STATUS		GENERAL SET-UP		SERVER GROUPS	
Hostname: MAIB-WDS-AP			MAIB-WDS-AP uptime is 10 hours, 16 minutes		
Wireless Services: WDS - Wireless Domain Services - Status					
WDS Information					
MAC Address	IPv4 Address	IPv6 Address	Priority	State	
bc16.6516.62c4	10.106.54.146	::	254	Administratively StandAlone - ACTIVE	
WDS Registration					
APs: 1		Mobile Nodes: 0			
AP Information					
Hostname	MAC Address	IPv4 Address	IPv6 Address	CDP Neighbor	State
MAIB-WDS-Client	f972.e924.40e6		::	BGL14-TACLAB	REGISTERED
Mobile Node Information					
MAC Address	IP Address	State	SSID	VLAN ID	BSSID
Wireless Network Manager Information					
IP Address	Authentication Status				

On the WDS Client AP, the WDS status is Infrastructure.

Hostname: MAIB-WDS-Client		MAIB-WDS-Client uptime is 10 hours, 57 minutes			
Wireless Services Summary					
AP					
WDS MAC Address	WDS IP Address	IN Authenticator	MN Authenticator	State	
bc16.6516.62c4	::	10.106.54.146	10.106.54.146	Infrastructure	

*Note:* The Output Interpreter Tool (registered customers only) supports certain *show* commands. Use the Output Interpreter Tool in order to view an analysis of *show* command output.

## CLI Verification Output on WDS AP

This procedure shows how to verify the WDS AP configuration:

```
MAIB-WDS-AP#sh wlccp wds ap
```

```
HOSTNAME MAC-ADDR IP-ADDR IPV6-ADDR STATE  
MAIB-WDS-Client f872.ea24.40e6 10.106.54.136 :: REGISTERED
```

```
MAIB-WDS-AP#sh wlccp wds statistics
```

```
WDS Statistics for last 10:34:13:  
Current AP count: 1  
Current MN count: 0  
AAA Auth Attempt count: 2  
AAA Auth Success count: 2  
AAA Auth Failure count: 0  
MAC Spoofing Block count: 0  
Roaming without AAA Auth count: 0  
Roaming with full AAA Auth count:0  
Fast Secured Roaming count: 0  
MSC Failure count: 0  
KSC Failure count: 0  
MIC Failure count: 0  
RN Mismatch count: 0
```

## CLI Verification Output on WDS Client AP

This procedure shows how to verify the WDS client AP configuration:

```
MAIB-WDS-Client#sh wlccp ap
```

```
WDS = bc16.6516.62c4, IP: 10.106.54.146 , IPV6: ::  
state = wlccp_ap_st_registered  
IN Authenticator = IP: 10.106.54.146 IPV6: ::  
MN Authenticator = IP: 10.106.54.146 IPv6::
```

## Troubleshoot

There is currently no specific troubleshooting information available for this configuration.