

AutoInstall on Autonomous Access Points Configuration Example

Contents

[Introduction](#)

[Prerequisites](#)

[Requirements](#)

[Components Used](#)

[Conventions](#)

[Configure](#)

[AutoInstall using DHCP](#)

[Example](#)

[Verify](#)

[Related Information](#)

[Introduction](#)

This document provides information on how to use the AutoInstall feature for LANs to automatically configure Cisco Aironet Autonomous Access Points (APs).

[Prerequisites](#)

[Requirements](#)

Cisco recommends that you have knowledge of these topics:

- Cisco Wireless Autonomous solutions
- Configuring a DHCP server on a Cisco IOS® router

[Components Used](#)

- Cisco Aironet 1200 Series APs that run Cisco IOS Software Release 12.3(8)JA2
- Cisco 2800 Series Router (used as DHCP server) that runs Cisco IOS Software Release 12.4(11)T
- Any TFTP server

[Conventions](#)

Refer to [Cisco Technical Tips Conventions](#) for more information on document conventions.

Configure

AutoInstall using DHCP

The AutoInstall using DHCP for LAN Interfaces feature provides the configuration of a new device automatically when the device is initialized. DHCP provides the framework for passing configuration information to hosts on a TCP/IP network. The AutoInstall process is initiated when a valid startup configuration file cannot be located in NVRAM.

There are two primary phases of the AutoInstall process:

- IP address procurement
- Download the configuration file

IP address procurement—In this phase, the device sends out a DHCP request looking for a DHCP server. The DHCP server responds by leasing out an IP address and returns the configured options (TFTP information in this case).

In the download configuration file phase, after you obtain an IP address, the AutoInstall process initiates attempts to download a configuration file from the TFTP server.

For more information on AutoInstall, refer to [AutoInstall Using DHCP for LAN Interfaces](#).

Example

This document's example has an out-of-the-box Cisco Aironet 1200 Series Autonomous AP that uses the AutoInstall for LAN feature to download the configuration file stored on the TFTP server.

For illustration purposes, the Cisco IOS router is used as DHCP server and a valid configuration file is stored on the root directory of the TFTP server.

In this document's example, the Cisco IOS router is used as the DHCP server. These IP addresses are used:

- 10.78.177.16 - TFTP server
- 10.78.177.30 - DHCP server

It is assumed that the Cisco IOS router is already configured and active on the network. Here, only the DHCP configuration required for this document is shown:

```
2800-ISR-TSWEB#show run
Building configuration...

Current configuration : 2029 bytes
!
!
ip dhcp pool autoinst
  network 10.78.177.0 255.255.255.192
  bootfile 1200_AP_cfg
  option 150 ip 10.78.177.16
!
```

Next, the TFTP server needs to be enabled and the valid configuration file must be stored in the

root directory of the TFTP server.

In this example, the TFTP server has been enabled and the configuration file has been stored in the root directory.

Verify

You need to boot up the out-of-the-box autonomous AP and verify if the AutoInstall feature works as expected.

Here are the logs from the AP Console:

```
*Mar  1 00:00:17.032: AUTOINSTALL

*Mar  1 00:00:32.216: %LINEPROTO-5-UPDOWN: Line protocol on Interface BVI1, changed
state to up

*Mar  1 00:00:40.350: %DHCP-6-ADDRESS_ASSIGN: Interface BVI1 assigned DHCP address
10.78.177.4, mask 255.255.255.192, hostname ap

Loading 1200_AP_cfg .from 10.78.177.16 (via BVI1): ![OK - 1885 bytes]

*Mar  1 00:01:03.662: %SYS-5-CONFIG_I: Configured from
tftp://10.78.177.16/1200_AP_cfg by console
```

As you can see from the logs, the AP has successfully downloaded the configuration file from the TFTP server. This can be verified by issuing the **show run** command on the AP:

```
1200_AP#show run
Building configuration...

Current configuration : 1885 bytes
!
version 12.3
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
service password-encryption
!
hostname 1200_AP
!
enable secret 5 $1$VhbX$6jqz9MceJfKZJ8HWmTbtn/
!
ip subnet-zero
ip domain name shc.org
ip name-server 167.94.17.92
!
!
<Snipped>
!
interface Dot11Radio0
no ip address
no ip route-cache
shutdown
!
encryption key 1 size 40bit 7 055C207F4663 transmit-key
```

```
encryption mode wep mandatory
!  
ssid ceteam  
!  
speed basic-1.0 basic-2.0 basic-5.5 6.0 9.0 basic-11.0 12.0 18.0 24.0 36.0 48.0 54.0  
station-role root  
bridge-group 1  
bridge-group 1 subscriber-loop-control  
bridge-group 1 block-unknown-source  
no bridge-group 1 source-learning  
no bridge-group 1 unicast-flooding  
bridge-group 1 spanning-disabled  
!
```

Related Information

- [**AutoInstall on Wireless LAN Controllers \(WLCs\) with Microsoft DHCP Server Configuration Example**](#)
- [**Basic Wireless LAN Connection Configuration Example**](#)
- [**Technical Support & Documentation - Cisco Systems**](#)