Configure Simple Network Management Protocol (SNMP) Views on a Switch

Objective

The Simple Network Management Protocol (SNMP) is an Internet-standard protocol used to manage devices on IP networks. The SNMP messages are used to inspect and communicate information about managed objects. SNMP uses Management Information Bases (MIBs) to store available objects in a hierarchical or tree-structured namespace that contains object identifiers (OIDs). An OID identifies the information in the MIB hierarchy that can be read or set via SNMP.

SNMP Views are a subset of MIB objects that can be assigned to an SNMP access group to control write, read, and notification privileges of SNMP users over MIB object information. A view is a user-defined label for a collection of MIB subtrees. Each subtree ID is defined by the OID of the root of the relevant subtrees. Either well-known names can be used to specify the root of the desired subtree or an OID can be entered.

This article provides instructions on how to configure the SNMP Views on your switch.

Applicable Devices

- Sx250 Series
- Sx300 Series
- Sx350 Series
- SG350X Series
- Sx500 Series
- Sx550X Series

Software Version

- 1.4.7.05 Sx300, Sx500
- 2.2.8.04 Sx250, Sx350, SG350X, Sx550X

Configure SNMP Views on your Switch

The Views page of the web-based utility of your switch allows you to create and edit SNMP views. The default views (Default and DefaultSuper) cannot be changed.

Views can be attached to groups in the Groups page or to a community which employs basic access mode through the Communities page.


Note: To know how to configure the SNMP Groups on a switch, click <u>here</u>. For instructions on how to configure SNMP Communities on a switch, click <u>here</u>.

View the SNMP Views Table

Step 1. Log in to the web-based utility of your switch then choose Advanced in the Display


Mode drop-down list.

Note: In this example, SG350X-48MP switch is used.




Note: If you have an Sx300 or Sx500 Series switch, skip to Step 2.

Step 2. Choose **SNMP** > **Views**.




The View Table displays the following information:




- View Name The name of the view.
- Object ID Subtree The subtree to be included or excluded in the SNMP view.
- Object ID Subtree View Displays whether the defined subtree is included or excluded in the selected SNMP view.

Step 3. (Optional) Check the **Filter** check box to filter the View Name that you want to be shown on the View Table.



Step 4. (Optional) Choose a view name from the View Name drop-down list.



The following views are created by default:


- Default Default SNMP view for read and read/write views.
- DefaultSuper Default SNMP view for administrator views.

Note: In this example, Default is chosen.

Step 5. (Optional) Click Go.



Step 6. (Optional) Click Clear Filter to clear the filter settings.



You should now have viewed the SNMP View on your switch.

Add a View in the View Table

Step 1. Click the **Add** button to add a new entry in the View Table.

View Name	Object ID Subtree	Object ID Subtree View
Default	1	Included
Default	1.3.6.1.6.3.13	Excluded
Default	1.3.6.1.6.3.16	Excluded
Default	1.3.6.1.6.3.18	Excluded
Default	1.3.6.1.6.3.12.1.2	Excluded
Default	1.3.6.1.6.3.12.1.3	Excluded
Default	1.3.6.1.6.3.15.1.2	Excluded
Default	1.3.6.1.4.1.9.6.1.101.98.1	Excluded
Default	1.3.6.1.4.1.9.6.1.101.2.7.2	Excluded
Add	Delete	

Step 2. Enter the name of the new SNMP view in the *View Name* field. The character limit for this field is 30.



Note: In this example, TCP is used as view name.

Step 3. In the Object ID Subtree area, click one of the following radio buttons that defines a method to select a node in the MIB tree that is included or excluded in the new SNMP view.

Note: In this example, Select from list is chosen.




The options are:

- Select from list Allows you to choose the node in the MIB tree from the available list.
- User Defined Allows the user to enter the object identifier that is not available in the Select From list. If this option is chosen, enter the OID in the *User Defined* field then skip to <u>Step 7</u>.


Note: For a list of OIDs of the Cisco Small Business Switches, click here.

Step 4. (Optional) Scroll down the list and choose an OID subtree from the list.




Note: In this example, tcp is chosen.

Step 5. (Optional) Use the **Up** arrow to go to the level of the parent and siblings of the chosen node and click the **Down** arrow to descend to the level of the children of the chosen node.




Note: In this example, the Down arrow is clicked.

Step 6. (Optional) Scroll down the list and a child from the list. If the Up button is chosen in Step 5, choose the parent instead.




Note: In this example, tcpAttemptFails is chosen.


<u>Step 7</u>. Check or uncheck the **Include in view** check box. If this is checked, the chosen MIBs are included in the view, otherwise they are excluded.



Step 8. Click **Apply** then click **Close**.



Step 9. (Optional) Click **Save** to save the settings to the startup configuration file.



You should now have successfully added a new SNMP view in the View Table of your switch.

Delete an SNMP View

Step 1. In the View Table, check the check box of the view that you want to delete.


View Table						
Filter: View Name equals to TCP \$ Go Clear Filter						
 ✓	View Name	Object ID Subtree	Object ID Subtree View			
0	TCP	1.3.6.1.2.1.6.7	Included			
	Default	1	Included			
	Default	1.3.6.1.6.3.13	Excluded			

Note: In this example, TCP view is chosen.

Step 2. Click **Delete**.

View Table						
Filter: View Name equals to TCP Go Clear Filter						
✓	View Name	Object ID Subtree	Object ID Subtree View			
	TCP	1.3.6.1.2.1.6.7	Included			
	Default	1	Included			
	Default	1.3.6.1.6.3.13	Excluded			
	Default	1.3.6.1.6.3.16	Excluded			
	Default	1.3.6.1.6.3.18	Excluded			
	Default	1.3.6.1.6.3.12.1.2	Excluded			
	Default	1.3.6.1.6.3.12.1.3	Excluded			
	Default	1.3.6.1.6.3.15.1.2	Excluded			
	Default	1.3.6.1.4.1.9.6.1.101.98.1	Excluded			
	Default	1.3.6.1.4.1.9.6.1.101.2.7.2	Excluded			
	DefaultSuper	1	Included			
Add Delete						

Step 3. (Optional) Click **Save** to save the settings to the startup configuration file.



You should now have successfully deleted an SNMP view from the View Table of your switch.